




MAINTENANCE



1. You can immediately walk on your new Titan Hybrid floor after installation.
2. You can walk on the floor during and immediately after installation. Ensure that temperature in the room is always above 5°C and below 35°C.
3. For dry maintenance, we advise a soft broom or vacuum cleaner. Make sure the vacuum cleaner is equipped with soft wheels and a special parquet brush to avoid scratches on your floor. It is important to understand that steam mops or wet mops are not recommended for any hard surface floor covering. Steam cleaners and wet mops however are permitted on Titan Hybrid. If using a steam cleaner, please ensure that a cloth covers the direct steam pressure on any device as this will help an even distribution of steam and heat. Keep the steam cleaner moving during cleaning and, for best results, clean the floor in the same direction as the planks have been installed.
4. For slightly damp and wet maintenance, we advise to use the recommended cleaning and maintenance kit. Be aware that the use of other cleaning products might damage your floor.
5. General spot cleaners are suitable for removal of most marks. Wipe up spills and stains as quickly as possible.
6. Protect furniture and chair legs. Avoid bringing dirt, water and sand indoors by providing a suitable floor mat at the door. Use (office) chairs and seats with soft wheels that are suitable for hard floors and/or use a suitable desk mat.
7. Never drag items of furniture over the floor but lift them up.
8. The smooth surface of your Titan Hybrid floor will not retain dirt or dust. Remove stubborn stains carefully with a citrus based cleaner or eucalyptus oil. Never use scouring products! Never use wax or varnish coating on the floor.